



Innovative “vanishing” elevator

Ultra-high capacity of 845 lb!

Sleek modern styling with transparent panels to blend with your home décor

Space-saving design; no hoistway required

Savaria® Telecab17 Home Elevator

MAXIMIZE YOUR LIVING SPACE



If you are looking for a space-saving, stylish and affordable mobility solution for your home, the Savaria Telecab17 is the answer for you. The Telecab17 is a two-stop elevator that travels through a simple floor cut-out for a vanishing elevator effect, leaving you more usable space. Available in two standard sizes – both with a capacity of 845 lb – the lift can typically handle multiple passengers as well as heavier mobility equipment. With a modular, fully enclosed drive tower which attaches to a support wall, no hoistway is required – so no need to worry about complex, costly installations.

 **savaria.**

Savaria® Telecab17 Home Elevator

MAXIMIZE YOUR LIVING SPACE



Travels through a simple floor cut-out



Authorized Savaria dealer:

- Fully enclosed drive tower designed for safety and aesthetics means that no hoistway or pit is needed
- Two stops and up to 23' (7 m) of travel
- Two standard cab sizes to choose from: 30" x 46", or 36" x 54"
- Rust-resistant powder-coated aluminum frame (white) with clear acrylic window panels
- Constant pressure controls for operation with keyless or keyed access on car and call stations
- Cab top sensor stops the unit from moving when pressure is detected
- Left or right hand opening door; hydraulic door closer
- Safety features include: interior lighting, emergency stop and alarm buttons, battery lowering in case of power failure as well as manual emergency lowering, telephone, non-skid platform, underpan sensor to stop the unit if it meets an obstruction, pressure relief valve to prevent platform overload, door interlock, and slack chain safety device
- Optional battery power for up to 5 trips up and down, in case of power failure

SPECIFICATIONS

Applications	Residential, indoor
Capacity	845 lb (384 kg)
Maximum travel distance	23' (7 m) with 2 stops
Cab sizes	W30" x L46" x H80" (762 mm x 1168 mm x 2032 mm) W36" x L54" x H80" (914 mm x 1372 mm x 2032 mm)
Speed	20 ft/min (0.1 m/s)
Floor cut-out	60.5" x 35.25" (1537 mm x 895 mm) for 30" x 46" cab 68.5" x 41.25" (1740 mm x 1048 mm) for 36" x 54" cab
Minimum overhead required	96" (2438 mm) to have 6" minimum clearance by code 92" (2337 mm) where code permits
Drive	2:1 roller chain hydraulic
Motor/pump	24 VDC, 3 hp (2.1 kW), gear type hydraulic pump
Warranty	36 months parts, ask for details

For Telecab17 only.

For other sizes or configurations ask your Savaria dealer about the original Telecab (500 lb capacity)

Your local authorized dealer can ensure your Savaria product is installed to comply with local and national codes. **Talk to a skilled Savaria dealer about how the Telecab17 can give you the mobility you need without major construction.**



www.savaria.com

2 Walker Drive, Brampton, ON Canada L6T 5E1

tel: 800.661.5112 fax: 905.791.2222